

HYDRA RINSE Stoelting Gravity Series: Stage 1 Cleaning Process

Words in **GREEN** signifies "ON"
Words in **RED** signifies "OFF"

1 Drain Product




- **Sleep Mode**, wait 4-5 hours
- **Freezing Cylinder(s)**
- Remove mix inlet regulator(s)
- **Clean Mode**
- Drain product
- Refrigerate or discard

2 Clean Hopper(s)



- **Main Power**, hold for 3 seconds
- Clean top hopper(s) & lid(s)
- Brush mix inlet hole(s)
- Fill freezing cylinder(s) with wand
- **Main Power**
- **Clean Mode**, wait 2-3 minutes

3 Drain Pre-wash & Remove Spigot(s)





- Drain pre-wash
- **Main Power**
- Remove spigot(s)

4 Install Bypass System



- Spray off & install bypass tube adapter(s) & bypass tubes into mix inlet hole(s)
- Terminate bypass hose to a suitable drain
- Replace hopper lid(s)

5 Install Pro-control Module



- Clean bottom of front door
- Wet all O-rings
- Install Pro-control
- Engage keeper switch
- Connect water supply

6 Install LEXX™ Cups





- Install 1 LEXX™ cup into each cup housing

7 Start the Pro-control




- **"ONE TOUCH"** to initialize the Pro-control cycle
- Audible beeps from Pro-control
- **Main Power**
- **Clean Mode**
- Clean any removed components
- **If performing Stage 2, flip to back**

8 Pro-control Cycle Complete




- "GREEN LED" blinks, cycle is done
- Press & release **"PLAY/PAUSE"**
- **Main Power**
- Disconnect water supply
- Remove left cup housing over bucket
- Remove bypass to drain
- Re-attach cup housing
- Disengage keeper switch & remove the Pro-control

9 Sanitize Front Door & Re-install Spigot(s)




- Clean the front door & all openings
- Leave apart or reassemble & re-fill the machine within 72 hours
- Perform self-clean on Pro-control

HYDRA RINSE



Words in **GREEN** signifies "ON"
Words in **RED** signifies "OFF"



1. "Reset-Cups-Program"

- Reset
- Register Cleaning Cycles
- Read # of Cleanings Available

2. "ONE TOUCH"

- Initialize Cleaning Cycles
- Self-Clean Mode when used simultaneously w/ "PLAY/PAUSE"

3. "Status Indicators" LEDs


- Power On/Cycle Initiated
- Cycle Paused
- Errors
- # of Registered Cleanings

4. "PLAY/PAUSE"

- Cancel/Conclude Cleaning
- Pause/Resume Cleaning
- Self-Clean Mode when used simultaneously w/ "ONE TOUCH"

Refer to the Manual for Full Instructions

Registration of Token Tag




- To register, hold the "TOKEN TAG" on the "HR Symbol"
- Keep "TOKEN TAG" in position, press and release the "RESET-CUPS-PROGRAM" button
- LED's will illuminate
- Once registered, a "Beep" will be heard & the "Status Indicators" blinking the number of stored cycles
- To finish, remove the "TOKEN TAG" from the registration zone, press and then release the "RESET-CUPS-PROGRAM" button
- The Pro-control is ready to use

HYDRA RINSE Stoelting Gravity Series: Stage 2 Cleaning Process

Words in **GREEN** signifies "ON"
Words in **RED** signifies "OFF"

1 Pause the Pro-control



- All 3 LED's start blinking about 3 ½ minutes into the cycle
- **"Play/Pause"**
- **Main Power**

2 Drain the Machine



- Disconnect water supply
- Remove left cup housing
- Remove bypass tubes to drain

3 Remove the Pro-control



- Re-install the left cup housing
- Remove the Pro-Control & set aside (do not push any additional buttons)
- Pro-Control will beep & green LED will blink while paused

4 Remove & Clean Internal Components



- Remove the freezer door & all internal components
- Clean each cylinder & all components using the wand, wipes and brushes
- Brush clean all door openings

5 Re-assemble Machine



- When all parts have been cleaned & sanitized:
- Reapply the proper lubricant to all appropriate parts
- Re-assemble the machine

6 Re-install the Pro-control



- Re-install the Pro-Control & connect the water supply
- Check that the water is still turned on & the bypass is properly installed

7 Resume Stage 1 Cleaning



- **"PLAY/PAUSE"**
- **Main Power**
- **Clean Mode**
- The Pro-Control will now start its sanitizing cycle
- **Revert to Stage 1 Step 8 to complete**